




Model XPH11RB/ZB Parts List

A = Standard Equipment

O= Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	183E64-0	HOUSING SET	1	
	C10 263005-3	RUBBER PIN 6	2	PC.
	C20 252126-6	HEX. LOCKING NUT M4-7	2	PC.
	D10	INC. 17		
002	852L51-9	XPH11 NAME PLATE	1	
003	266429-2	TAPPING SCREW 3X16	8	PC.
004	457020-9	SPEED CHANGE LEVER	1	
005	233025-1	COMPRESSION SPRING 2	2	PC.
006	419041-9	F/R CHANGE LEVER	1	PC.
007	650689-0	SWITCH C3JW-2B	1	PC.
008	251468-5	- FLAT HEAD SCREW M6X22	1	PC.
009	763241-6	KEYLESS DRILL CHUCK 13	1	
010	123587-6	CHANGE LEVER ASS'Y	1	
	D10	INC. 5		
011	123867-0	GEAR ASSEMBLY	1	
012	266490-9	TAPPING SCREW PT 2X6	3	PC.
013	620555-5	CONTROLLER	1	
014	629228-7	STATOR	1	PC.
015	619410-6	ROTOR	1	
016	643874-2	TERMINAL	1	PC.
017	183E64-0	HOUSING SET	1	
	C10 263005-3	RUBBER PIN 6	2	PC.
	C20 252126-6	HEX. LOCKING NUT M4-7	2	PC.
	D10	INC. 1		
018	424517-3	CUSHION	1	PC.
019	809U04-3	CAUTION LABEL	1	
023	620549-0	LED CIRCUIT	1	
A01	251314-2	+ SCREW M4X12	1	PC.
A02	346449-3	HOOK	1	PC.
A03	BL1820B	BATTERY BL1820B SET (197257-3)	2	(XPH11RB)
A04	141856-3	PLASTIC CARRYING CASE COMPLETE	1	PC. (XPH11RB)
	C10 162302-3	LATCH	2	PC. (XPH11RB)
A05	450128-8	BATTERY COVER	1	PC. (XPH11RB)
A06	***DC18RC	DC18RC FAST CHARGER	1	PC. (XPH11RB)
	D10	COMPO-PARTS		