



DE


GERMANY

Diagram / Parts List

DMR102

JOB SITE RADIO





DMR102 / JOB SITE RADIO

Item	Sub	Parts No.	Parts Description	Qty	I/C	E/C No.	Close No.	Remark
001		SE00000140	CIRCUIT BOARD A ASSY	1			Y06465	
	C10	SE00000141	CIRCUIT BOARD A	1			Y06465	
	C20	SE00000142	CIRCUIT BOARD A JACK	1			Y06465	
	C30	SE00000143	CIRCUIT BOARD A SPEAKER WIRE	1			Y06465	
	C40	SE00000144	VOLTAGE DETECT SWITCH ASSY	1			Y06465	
001-1		SE00000266	PCB-A ALL ASS'Y JP	1	S	Y06465		
	C10	SE00000267	CIRCUIT BOARD A	1		Y06465		
	C20	SE00000268	PCB-A DC JACK ASS'Y	1		Y06465		
	C30	SE00000269	PCB-A PWR WIRE ASS'Y	1		Y06465		
	C40	SE00000270	PCB-A BATT. DET ASS'Y	1		Y06465		
	C50	SE00000220	CIRCUIT BOARD C AUX-2 ASS'Y	1		Y06465		
002		SE09163102	SCREW M3X10	5				
003		SE00000155	CIRCUIT BOARD C ASSY	1			Y06465	
003-1		SE00000297	CIRCUIT BOARD C ASSY	1	S	Y06465		
004		SE09163102	SCREW M3X10	6				
005		SE09090011	SCREW 1.7	13				
006		SE020PC020	POWER BUTTON HOLDER	1				
007		SE00000157	POWER BUTTON (GRY)	1				
008		SE020PC030	PRESET BUTTON HOLDER	1				
009		SE00000158	PRESET BUTTON (GRY)	1				
010		SE09064161	SCREW M4X16	1				
011		SE09163102	SCREW M3X10	2				
012		SE09064161	SCREW M4X16	2				
013		SE00000204	FRONT CABINET ASSY	1				
015		SE09064161	SCREW M4X16	1				
016		SE00000159	FRONT BUMPER	1				
017		SE0338PC5Z	FRONT BAR	2				
018		SE00000160	SCREW PTHE6X47(CR)	4				
019		SE00000161	ROTARY KNOB	1				
020		SE21B1110A	ROTARY KNOB RING	1				
021		SE0335PC5Z	JACK COVER	1				
022		SE09173106	HEX SCREW M3X10	1				
023		SE00000162	BATTERY COVER BUMPER	1				
024		SE09176166	HEX SCREW M6X16	2				
025		SE09176166	HEX SCREW M6X16	2				
026		SE00000165	REAR BUMPER	1				
027		SE00000166	BATTERY COVER	1				
028		SE09163102	SCREW M3X10	2				
029		SE00000168	PACKING	1				
030		SE00000169	SUPPORT BAR	1				
031		SE00000170	SPRING-L	1				
032		SE00000171	SPRING-R	1				
033		SE09163102	SCREW M3X10	2				
034		SE00000173	SPRING HOLDER-R	1				
035		SE09163102	SCREW M3X10	2				
036		SE00000175	SPRING HOLDER-L	1				
037		SE0307PC5Z	BACK UP BATTERY COVER	1				
038		SE021E9010	BATTERY CONTACT (+)	1				
039		SE021E9020	BATTERY CONTACT (-)	1				
040		SE021E9030	+/- BATTERY CONTACT ASS'Y	1				
041		SE09163452	SCREW M3X45	1				
042		SE00000176	SCREW PTHE6X20(CR)	1				
043		SE00000177	HANDLE HOLDER(R)	1				
044		SE00000179	HANDLE	1				
045		SE00000180	HANDLE HOLDER (L)	1				
046		SE00000176	SCREW PTHE6X20(CR)	1				
047		SE09176166	HEX SCREW M6X16	1				
048		SE00000184	SPRING	2				
049		SE09994007	STEEL BALL	2				
050		SE09994007	STEEL BALL	2				
051		SE00000184	SPRING	2				
052		SE09176166	HEX SCREW M6X16	1				
053		SE00000187	HANDLE SUS-PLATE (R)	1				
054		SE09163452	SCREW M3X45	1				
055		SE00000188	REAR CABINET	1				

Interchange

O : Yes

X : No

< : the new part can be substituted for the current.

> : the current part can be substituted for the new.

S : Interchangeable as a set.

DMR102 / JOB SITE RADIO

[illegible]