




Model LW1400 Parts List

A = Standard Equipment

O= Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	213858-0	O-RING 65	1
002	265122-5	PAN HEAD SCREW M5X20	4 PC.
003	224299-5	FLANGE 90	1 PC.
004	123478-1	TOOLLESSBOLT ASSEMBLY	1
005	418142-0	PLUG	1 PC.
006	418142-0	PLUG	1 PC.
007	161398-1	SAFETY GUIDE	1
008	265121-7	+ FLAT HEAD SCREW M6	1 PC.
013	213180-5	O RING 14	1 PC.
014	257255-0	RING 17	1 PC.
015	224299-5	FLANGE 90	1 PC.
016	257255-0	RING 17	1 PC.
017	161400-0	SAFETY COVER	1
018	211282-1	BALL BEARING 6203ZZ	1 PC.
019	319393-7	BEARING BOX	1
020	227811-0	HELICAL GEAR 50	1
021	324321-9	SPINDLE	1 PC.
022	210067-2	BALL BEARING 6000ZZ	1 PC.
023	183C14-3	HANDLE SET	1
	D10	INC. 30	
024	650716-3	SWITCH TGC31B	1
025	418140-4	SWITCH LEVER	1 PC.
026	418139-9	SWITCH LOCK	1 PC.
027	231397-8	COMPRESSION SPRING 4	1 PC.
030	183C14-3	HANDLE SET	1
	D10	INC. 23	
031	411478-6	SWITCH BUTTON	1 PC.
032	266326-2	TAPPING SCREW 4X18	4 PC.
034	265104-7	PAN HEAD SCREW M5X40	3 PC.
038	266326-2	TAPPING SCREW 4X18	2 PC.
039	687124-5	STRAIN RELIEF	1 PC.
040	664478-7	POWER SUPPLY CORD #14-2-3.0	1 PC.
041	682574-9	CORD GUARD 10-90	1 PC.
042	851S34-8	LW1400 NAME PLATE	1
043	143760-2	MOTOR HOUSING COMPLETE	1
	C10	643712-8 BRUSH HOLDER	2 PC.
	C20	808N19-5 CAUTION LABEL	1 PC.
044	643700-5	BRUSH HOLDER CAP 7-18	2 PC.
045	CB203	CARBON BRUSH CB-203 (194991-6)	1 SET
046	265104-7	PAN HEAD SCREW M5X40	4 PC.
047	593907-2	FIELD ASS'Y 115V	1
	C10	654197-3 RING TERMINAL	2 PC.
	C20	654502-4 CONNECTOR P-2	2 PC.
048	265A13-6	TAPPING SCREW 5X85	2
049	418143-8	BAFFLE PLATE	1 PC.
050	210070-3	BALL BEARING 6200ZZ	1 PC.
051	513461-0	ARMATURE ASS'Y 115V	1
	D10	INC. 50,52-54,97	
052	240164-0	FAN 80	1 PC.

053	267714-6	WASHER 15	1 PC.
054	211240-7	BALL BEARING 6200ZZ	1 PC.
055	324322-7	STOPPER	1 PC.
056	233372-0	COMPRESSION SPRING 7	1 PC.
057	143464-6	GEAR HOUSING COMPLETE	1
C10	263029-9	RUBBER PIN 6	1 PC.
058	951163-4	SPRING PIN 5-20	1 PC.
059	272027-2	HANDLE 120	1 PC.
060	324323-5	WISE SCREW	1 PC.
063	266321-2	H.S.SET SCREW(FLAT POINT)M6X16	1 PC.
065	313114-9	WISE NUT	1 PC.
066	345311-9	PLATE	1 PC.
067	317662-0	SCREW GUIDE	1 PC.
068	951175-7	SPRING PIN 5-36	1 PC.
069	951110-5	SPRING PIN 4-16	1 PC.
070	265125-9	PAN HEAD SCREW M8X30	2 PC.
071	266996-7	COLLAR BOLT M10X20	1
072	271331-6	KNOB 40	1
073	346970-2	GUIDE PLATE	1
074-1	252183-4	HEX.NUT M10-17	1 PC.
075	942251-8	SPRING WASHER 10	1 PC.
076	253197-6	FLAT WASHER 10	1 PC.
077	331648-0	PIPE 20-128	1 PC.
078	233633-8	TORSION SPRING 33	1
081	161399-9	SPARK GUARD	1
082	265144-5	PAN HEAD SCREW M6X12	1 PC.
083	421834-2	CUSHION	3 PC.
084	253197-6	FLAT WASHER 10	1 PC.
085	265509-1	HEX.BOLT M10X140	1 PC.
086	161397-3	BASE	1
087	961004-6	RETAINING RING S-8	1 PC.
088	267257-8	FLAT WASHER 8	1 PC.
089	256545-8	PIN 16	1 PC.
090	961056-7	RETAINING RING S-16	1 PC.
091	267257-8	FLAT WASHER 8	1 PC.
092	346636-4	WISE PLATE	1 PC.
093	253903-9	WAVE WASHER 6	1 PC.
097	681630-2	INSULATION WASHER	1 PC.
098	911103-4	PAN HEAD SCREW M4X6	2 PC.
099	346971-0	SPARK COVER	1
100	266264-8	H.S.SET SCREW(FLAT POINT)M5X6	1 PC.
101	272286-8	LEVER 125	1
102	253197-6	FLAT WASHER 10	1 PC.
103	257389-9	SLEEVE 11	1
104	253180-3	FLAT WASHER 10	1 PC.
105	216413-7	THRUST NEEDLE CAGE 1024	1 PC.
106	253353-8	THIN WASHER 10	1 PC.
107	253353-8	THIN WASHER 10	1 PC.
108	216413-7	THRUST NEEDLE CAGE 1024	1 PC.
109	253353-8	THIN WASHER 10	1 PC.
110	961014-3	STOP RING E-8	1 PC.
111	161402-6	GUIDE BASE	1
112	257390-4	SLEEVE 20	2
113	961014-3	STOP RING E-8	1 PC.
114	213011-8	O RING 7	1 PC.
115	326624-7	STOPPER PIN	1

116	922311-2	HEX. SOCKET HEAD BOLT M6X12	1 PC.
117	942151-2	SPRING WASHER 6	1 PC.
118	931302-2	HEX. NUT M6	1 PC.
119	135708-8	WISE ASS'Y	1
	D10	INC. 58-60,65-69,87-92	
A01	A-93859-5	CUTTING WHEEL 14"	1 PC.